

## **Product information**

## WestWood® 800 Drainage Mat



## **Short description**

The WestWood® 800 Drainage Mat is especially designed for use in the WestWood® drainage system. The mat is adhered to the substrate using a special tile adhesive.

Please follow the WestWood® drainage system installation instructions for this. The Wecryl balcony waterproofing system is applied to the mat.

Material

Polyethylene film, filled with bonded sand and fleece-laminated on both sides

Characteristics

Colour: light greyTop surface printedEasy to install

Areas of application

As a drainage and isolation mat in the WestWood® drainage system.

**Dimensions** 

Length: 5 m Width: 1 m

Thickness: approx. 3 mm

Weight

approx. 10 kg per unit approx. 2 kg/m<sup>2</sup>

Storage

Store products in their original packaging and in a cool, dry, frost-free place.

Information on safety and

risks

Please refer to the safety data sheets for the products used.

## **General information**

The preceding information, especially with regard to the application of the products, is based on extensive development work and many years of experience and is provided as the best of our knowledge.

However, the wide variety of requirements and conditions on site mean it is necessary for the installer to test the product to verify its suitability for the intended purpose. Only the most recent version of the document is valid. We reserve the right to make changes to reflect advances in technology or

improvements to our products.

Last revised: 1 February 2022